



GENUINE PARTS

INSTALLATION INSTRUCTIONS

- 1. **DESCRIPTION:** First Aid Kit
- 2. **APPLICATION:** Maxima, Altima, Sentra, Pathfinder, Murano, 350Z, 370Z, Quest, Frontier Crew Cab, Frontier King Cab, Titan Crew Cab, Titan King Cab, Armada, Rogue, Versa, Cube, Juke, NV
- 3. **PART NUMBER:** 999M1 ST000

4. KIT CONTENTS:

| Item | Qty. | Description | Part Number | Service Part Number |
|------|------|---------------|--------------|---------------------|
| A | 1 | First Aid Kit | 057T7FRSTK92 | 999M1 ST000 |



A

- 5. **TOOLS REQUIRED:**

None

6. INSTALLATION PRECAUTIONS / NOTES:

WARNING

- Install first aid kit per instructions to avoid sliding or shifting.
- In a sudden stop or collision unsecured cargo could cause personal injury.

INSTALLATION INSTRUCTIONS – First Aid Kit

7. INSTALLATION PROCEDURE:

- 350Z: Behind passenger seat in storage compartment with lid closed.
- 370Z: With spare tire
- QUEST (2002 and earlier): Behind rear seat attached to hanging carpet strip on passenger side.
- QUEST (2004 to 2010): In small storage area on driver's side of third row seating.
- QUEST (2011 and Later): In rear under floor compartment with lid closed
- FRONTIER KING CAB:
 - 1) Jump seat option models:
 - a) Remove twist nuts on plastic seat cover for rear seat base on passenger side.
 - b) Place kit in location, replace cover and replace twist bolts.
 - 2) Without Jump seat option:
 - a) Under driver seat behind metal seat brace, with Velcro side down.
- FRONTIER CREW CAB: Behind right rear folding seat back.
- TITAN CREW CAB / KING CAB: Behind rear seat with Velcro towards rear of vehicle.
- ARMADA / ROGUE / JUKE / PATHFINDER / MURANO: In rear under floor compartment with lid closed.
- VERSA: In map pockets of front doors.
- CUBE: In glove box.
- NV: In front passenger door map pocket.
- ALL VEHICLES WITH TRUNK: Inside trunk.